

GEONEX BREAK-OUT BENCH

GEONEX BREAK-OUT BENCH TO BREAK OUT AND TO BREAK IN CONNECTIONS.



The Break out Bench is a great help when servicing, maintaining and repairing a DTH-hammer. The Break out Bench is operated hydraulically. The hydraulic power can be produced by some mobile device such as a Wheel Loader, or the Bench could be equipped with the Geonex Power Pack. Geonex manufactures two different break-out bench models.

APPLICATIONS FOR GEONEX BREAK-OUT BENCH

✓ **Drill rod etc. connection break out and break in**

The Bench may also be used e.g. opening jammed drill pipe couplings.

✓ **Down The Hole hammer service**

You can easily open the back head and chuck of the hammer to service the equipment efficiently.

✓ **Geonex Power Pack compatible**

The Bench can be equipped with the Geonex Power Pack models PP37, PP90 and PP180.

TECHNICAL INFORMATION

Geonex Break-out Bench HW8

	HW 8
Suitable hammer sizes	4"-8"
Length mm (ft in)	1210 (4')
Width mm (ft in)	1400 (4' 8")
Height mm (ft in)	1260 (4' 2")
Weight kg (lb)	450 (990)
OPTION Electrical power pack	230 v
OPTION	Hammer & rod spanners

Geonex Break-out Bench HW24

Suitable hammer sizes	8"-24"
Length mm (ft in)	2450 (8' 1")
Width mm (ft in)	1710 (5' 8")
Height mm (ft in)	1360 (4' 6")
Weight kg (lb)	2400 (5300)
OPTION Electrical power pack	380 v
OPTION	Hammer & rod spanners



GEONEX OY

Tel. +358 400 693 143

info@geonex.fi

Teollisuustie 9, FI-95600 Ylitornio, Finland

FOR MORE INFORMATION VISIT

www.geonex.fi

GEONEX BREAK-OUT BENCH

GEONEX BREAK-OUT BENCH TO BREAK OUT AND TO BREAK IN CONNECTIONS.

Geonex Break-out Bench HW24	
OPTION	Tong vise



GEONEX OY
Tel. +358 400 693 143
info@geonex.fi
Teollisuustie 9, FI-95600 Ylitornio, Finland

FOR MORE INFORMATION VISIT
www.geonex.fi